

# Gommasol

## Rubber streak remover

- ▲ Special, solvent-based cleaner for removing rubber streaks and abraded rubber from industrial floorings
- ▲ High cleaning power
- ▲ Low-odour
- ▲ Easy to use



### Area of application

Can be used on solvent-resistant floorings. Not suitable on surfaces sensitive to solvents, e.g. floors containing asphalt and bitumen as well as plastic surfaces (e.g. PVC).

### Application

Please test on a small inconspicuous spot before first application. Adjacent areas and objects must be protected.

#### Rubber streak removal:

Pour the product (undiluted or diluted 1:1 to 1:2 with water) in a suitable spray unit with foam nozzle and distribute, leave for approx. 10 minutes to react. For normal soiling or local use, the dirty solution can be removed by mechanical wet cleaning with a scrubber drier and 1% Dopomat-forte solution as part of routine cleaning.

#### Basic cleaning (mechanical wet cleaning):

In case of very heavy soiling or use on a large area, spray cleaner on the floor and then scrub thoroughly using a single disc machine and green pad. Then vacuum up the dirty solution. Remove product residue with a 1% solution of Dopomat-forte.



### Note

Kiehl accepts no liability or responsibility for damage caused as a result of incorrect use or application of the product. Not a consumer product according to 1999/44/EC Art. 1! For professional use only!

### Ingredients (according to 648/2004/EC)

Nonionic surfactants 5–15%, water-soluble solvents, additives.  
pH value (concentrate): approx. 6

pH value (ready-to-use solution): approx. 7

### Classification

Classification (in concentrate): GHS07, Warning. H302+H312+H332 Harmful if swallowed, in contact with skin or if inhaled. H319 Causes serious eye irritation. H315 Causes skin irritation. P271 Use only outdoors or in a well-ventilated area. P280 Wear protective gloves/eye protection. P301+P330+P331 IF SWALLOWED: Rinse mouth. Do NOT induce vomiting. P305+P351+P338 IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing. Contains: Butoxyethanol (INCI)

Art. No.  
j050715

Packaging unit (PU)  
Carton of 1 x 5 L canister

Numbers of PU per pallet  
60